


BATTERY SINGLE SHOT STREAMER MACHINE
USER MANUAL



FC RoHS CE

DISCLAIMER

WARNING

Read this manual carefully before installing and/or using this product. Failure to read the manual and to follow the printed instructions may lead to personal injury and/or damage to the product.

FORWARD

Congratulations! Thanks for purchase from us.

This manual contains all information required for the intended use of the equipment. Deviation from the described intended use can result in a hazardous situation and/or property damage.

This manual includes notes and warnings on safe operation of the equipment.

LIABILITY

Accepts no liability for claims from third parties arising from unauthorised use, use other than that stated in this manual, and use other than in accordance with the General Conditions registered at the Chamber of Commerce.

Refer further to the General Conditions. These are available on request, free of charge.

Although considerable care has been taken to ensure a correct and suitably comprehensive description of all relevant components, the manual may nonetheless contain errors and inaccuracies.

Should you detect any errors or inaccuracies in the manual, we would be grateful if you would inform us. This helps us to further improve our documentation.

TECHNICAL DATA



Product Name	Battery Single-shot Streamer Launcher
Voltage	DC12V
Power	30W
Control Mode	DMX512 / Remote
DMX Channel	1
Spray Height	6-12 m
N.W	2.6KG
G.W	3KG
Product Size	16 x 23 x 17 cm
Packing Size	30 x 30 x 23 cm

CHANNEL DESCRIPTION

4 CHS

CHANNEL 1	Spray Together (Multiple in series)
CHANNEL 2	From Left to Right (Multiple in series)
CHANNEL 3	From Right to Left (Multiple in series)
CHANNEL 4	From the middle to both sides (Multiple in series)

REMOTE DESCRIPTION

	Spray Together (Multiple in series)
	From the middle to both sides (Multiple in series)

+	From Left to Right (Multiple in series)
-	From Right to Left (Multiple in series)

PRECAUTIONS

- ✧ When the machine is not used for more than one month, it must be guaranteed to be charged once a month to avoid shortening the battery life.
- ✧ This machine remote control can control multiple machines with one remote control.
- ✧ The fuse needs to be cut off.
- ✧ The inside is kept dry, do not pour the wine into the machine.
- ✧ Please use the quality guaranteed fireworks bomb.

FEATURES

- ✧ Fireworks can adjust the angle 360 degrees.
- ✧ Independent research and development of lithium battery with short circuit protection.
- ✧ Independent research and development of color screen motherboard.
- ✧ Independent research and development design appearance.
- ✧ The machine is small and easy to carry.

INSTRUCTIONS

- 1 confetti cannons need to be loaded into the barrel of the 1 Shot Streamer Launcher. Each cannon is held in place in the barrel with a thumb screw , The angle of the transmitter can be adjusted.
- Open the power.
- The Single Shots Streamer Launcher can be operated with DMX or remote , Refer to the above instructions.

TROUBLESHOOTING

Always contact us if any malfunctions or errors occur that can not be solved with the instructions as described in this manual.

MAINTENANCE

To achieve the maximum service life of Battery Single-shot Streamer Launcher you must regularly clean the Battery Double-shot Streamer Launcher and test if it is functioning correctly. Contact us if the Battery Single-shot Streamer Launcher is not functioning correctly.

DANGER

Do not replace parts yourself. Always consult us if necessary.
